

Gemini PVC

Installation Guide Lines

Allow Gemini PVC to acclimatise in situ 24 hours prior to installation, insuring a working ambient temperature of 18 o Celsius

Good surface preparation is essential for a successful installation.

The horizontal structure should be free of any adhesive residues or contaminants, it should be dry (test floor for damp if in doubt), smooth, dust free & structurally sound.

Gemini PVC Reducing Strip

1. Using a tape measure, pencil & sharp fitting knife, Measure, mark and cut the reducing strip to size.
2. Apply Grabfast Gold Adhesive to the underside of the featheredge strip and to the subfloor, allow the adhesive to become touch dry.
3. 3. Introduce the featheredge to the subfloor, then apply even pressure using a Gemini hand held roller ensuring any air bubbles are removed and full contact is made with the floor.