

## Gemini PVC

### Installation Guide Lines

Allow Gemini PVC to acclimatise in situ 24 hours prior to installation, insuring a working ambient temperature of 18 o Celsius

Good surface preparation is essential for a successful installation.

All existing wall decorative finishes should be removed below the sit-on skirting line.

The vertical structure should be free of any adhesive residues or contaminants, it should be dry (test walls for damp if in doubt), smooth, dust free & structurally sound.

Vertical wall smoothing products should meet with the subfloor, paying particular attention to external/internal corners

**Gemini PVC should not be installed over existing floor coverings or linings.**

**Gemini PVC Sit-On Skirting, installed after floor covering installation.**

1. Using a pencil, mark walls at the required height, then join the pencil marks using a chalk line.
2. Tools-Tape measure, pencil & sharp fitting knife. Measure, mark and cut the sit-on skirting to size.
3. Internal mitres to be scribed in using a pair of dividers, external mitres chamfered back on upright to provide perfect joint.
4. Lay sit-on skirting face down on disposable protection ensuring no overspray to finished subfloor.
5. Apply Grabfast Gold to the back of the Sit-on skirting and wall. Allow the adhesive to become touch dry.
6. Introduce the sit-on skirting to the wall where it meets with the subfloor, apply even pressure to the full length, ensuring full contact is made, using a Gemini hand held roller ensuring any air bubbles are removed and full contact is made with floor & wall.