

Gemini PVC

Installation Guide Lines

Allow Gemini PVC to acclimatise in situ 24 hours prior to installation, insuring a working ambient temperature of 18 o Celsius

Good surface preparation is essential for a successful installation. All existing wall finishes should be removed below the capping line.

The vertical structure should be free of any adhesive residues or contaminants, it should be dry (test walls for damp if in doubt), smooth, dust free & structurally sound.

Vertical wall finishes should meet with the subfloor, paying particular attention to external/internal corners

Gemini PVC should not be installed over existing floor coverings or linings.

Gemini PVC Capping Strip

1. Using a pencil, mark the walls at the required height of the capping strip, then join the pencil marks using a chalk line.
2. Apply Grabfast Gold Spray Adhesive to the wall at the required height and to the back of the capping strip. Allow the adhesive to become touch dry.
3. Introduce the capping strip to the wall surface, using the chalk line as a guide, then apply even pressure using a Gemini hand held roller ensuring any air bubbles are removed and full contact is made with the wall.
4. External corners can be mitred or wrapped, internal corners should be butt fitted, insuring one section is scribed to the other.