

## Gemini PVC

### Installation Guide Lines

Allow Gemini PVC to acclimatise in situ 24 hours prior to installation, insuring a working ambient temperature of 18 o Celsius

Good surface preparation is essential for a successful installation.

All existing wall decorative finishes should be removed below the Flat Skirting line.

The vertical structure should be free of any adhesive residues or contaminants, it should be dry (test walls for damp if in doubt), smooth, dust free & structurally sound.

Vertical wall smoothing products should meet with the subfloor, paying particular attention to external/internal corners

**Gemini PVC should not be installed over existing floor coverings or linings.**

**Gemini PVC Flat Skirting should be installed before floor covering installation.**

1. Using a pencil, mark walls at the required height, then join the pencil marks using a chalk line.
2. Tools-Tape measure, pencil & sharp fitting knife. Measure, mark and cut the Flat Skirting to size.
3. Internal mitres to be scribed in using a pair of dividers, external mitres chamfered back on upright to provide perfect joint.
4. Lay Flat Shirting face down on disposable protection ensuring no overspray to finished subfloor.
5. Apply Gemini Adhesive to the back of the Flat Skirting and wall. Allow the adhesive to become touch dry.
6. Introduce the Flat Skirting to the wall where it meets with the subfloor, apply even pressure to the full length, ensuring full contact is made, using a Gemini hand held roller ensuring any air bubbles are removed and full contact is made with floor & wall.