

Gemini Semi Flexible PVC Tile Cap

Installation Guide Lines

Allow Gemini PVC to acclimatise in situ 24 hours prior to installation, insuring a working ambient temperature of 18o Celsius

Good surface preparation is essential for a successful installation.

The structure where Tile Cap is to be fitted should be free of any old adhesive residues or contaminants, it should be dry (test walls for damp if in doubt), smooth, dust free & structurally sound.

Gemini Tile Caps are fitted, generally at low level (100mm to 150mm above finished floor level) as a transition strip between a wall finish (ceramic tiles ect) and a resilient floor finish that has been coved up to form a skirting.

Gemini Tile Cap should be fitted prior to wall finish and floor finish.

1. Using a pencil, mark walls at the required height to where profile is to be fitted, then join the pencil marks using a chalk line.
2. Cut Gemini Tile Cap to size using a hacksaw and mitre block as required, alternatively a compound or chop saw can be used with a suitable blade.
3. Gemini Tile Cap can be adhered using Grabfast Gold and should also be mechanically fixed using appropriate screws.